



1998-2002 Honda Accord Distributor Rotor Replacement

Replace the distributor rotor on 98-00 Honda Accords with an F23A5 engine.

Written By: Miroslav Djuric



INTRODUCTION

Use this guide to replace your Honda Accord's distributor rotor. This specific guide was created for a non-VTEC [F23A5](#) engine, but other 4-cylinder Honda engines will be similar enough to follow the same basic steps. You may have to remove the engine cover in later Accord models.



TOOLS:


- [.25" Socket Wrench](#) (1)
- [8mm Deep Socket](#) (1)
- [Probe and Pick Set](#) (1)
- [Phillips #2 Screwdriver](#) (1)



PARTS:

- [Honda F23A5 Distributor Rotor](#) (1)

Step 1 — Distributor Cap





- Before disconnecting the spark plug wires, be sure to trace their orientation from the individual cylinders back to the distributor cap.
 - The cylinders are ordered from left to right when viewing the engine from the front of the car, with cylinder #1 being closest to the passenger side of the vehicle.
- ☑ Mark the order of the spark plug wires on the new distributor cap with a silver sharpie marker -- it will make reinstallation much easier.

Step 2




- Disconnect the four spark plug wires from the distributor cap by pulling their connectors straight away from the sockets on the distributor cap.
- ⓘ It may be helpful to slightly twist the wires as you pull them.

Step 3



- Use a 1/4" drive, 8 mm deep socket to remove the three hex bolts securing the distributor cap to the engine.

 The position of the third bolt is not visible in the second picture.

Step 4



- Pull the distributor cap away from the engine and set it aside.

Step 5



- Use a dental pick or a small screwdriver to gently remove the D-shaped o-ring around the distributor cap flange.
- Install a new o-ring in the seal recess, making sure that it is sitting flush against the flange.

Step 6 — Distributor Rotor



- Remove the single #2 Phillips screw securing the distributor rotor to the shaft.

Step 7



- Pull the distributor rotor straight off its shaft, being careful not to rotate the shaft as you remove it.
- ☑ When installing the new distributor rotor, press it onto the shaft with the screw holes aligned axially.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-10-03 10:42:12 AM.